
ATTENTION APPLE IIe OWNERS:

If you do not have a **"Mouse Card"** installed in your machine you will have to perform the following procedure in order to run the chess program.

1. Insert the chess disk in the boot drive.
2. Turn the computer on.
3. While the program is loading (or after the program has loaded and the "demo" has started), depress and hold down
 - A. the Ctrl (control) key
 - B. the Reset key
 - C. the "Closed Apple" key

When these three keys are pressed at the same time, the computer will begin to run a diagnostic routine. When this is finished ("Kernel Okay") you may boot the chess disk by pressing Ctrl & Reset. The program will load, and will begin with a short demonstration of how it works. Stop the demo and begin to play by pressing either the Return key or a game paddle knob (depending on which you wish to use - paddles or keyboard).

Note: the "Nice Chess" program will not work with joysticks, and you may have to disconnect any joysticks that are plugged in to the system for the program to operate correctly.