

CHAPTER THREE - RAMFACTOR PARTITION MANAGER	15
About the Partition Manager	15
Accessing the RamFactor Partition Manager (RPM) menus	15
Selecting a RAMdisk Partition	16
Configuring a RAMdisk Partition	17
Naming a Partition	17
Clearing a Partition	17
Sizing the Partitions	18
ProDOS, Pascal 1.3, and CP/AM Partition Sizes	18
Dos 3.3 Partition Sizes	18
Example Partition Sizes	18
Booting a Partition	19
Changing Partitions	20
APPENDICES	22
A: Adding Memory to the RamFactor	24
Introduction	24
Where to Get Chips	24
Installing the Memory Chips	25
B: Testing the RamFactor	27
Test on AW 2 Expander Disk	27
Test in Firmware	28
C: RamFactor Accessories	30
RamCharger	30
RamFactor 4 Meg Expander	31
D: Programmer's Reference	32
Introduction	32
Description of RamFactor	32
RamFactor Partition Manager Firmware	32
ProDOS	34
Pascal 1.3	34
DOS 3.3	34
Patches Made to DOS 3.3	35
Operating System Identification	36
RamFactor Hardware	36

APPENDIX E

A Brief ProDOS Tutorial

This is a brief explanation of the **Professional Disk Operating System, ProDOS**, for those who are completely new to it. All of this information and more is included in your *Apple Owner's Guide*, but we have provided it here for your convenience.

Operating System

ProDOS is one of several operating systems for the Apple. Others include DOS 3.3 and Pascal. Operating systems, as defined in the *Apple Owner's Guides*, are programs that control how information is loaded into memory, how the computer handles the information, how the information is stored on a disk, and how the computer communicates with the printer and other peripherals.

Naming Volumes

ProDOS must have a way to locate which disk (often called "volume") you want to access. Instead of typing in the location of the disk as in DOS 3.3 (ex: S6,D1), you simply type in the name of the disk (the volume name). Some rules for volume names are

- 1) Name can include letters, numbers, or periods but not spaces
- 2) Name must begin with a letter
- 3) Name can be up to 15 characters long

These rules also hold true for subdirectory names.

Root Directory and Subdirectory

The main directory of the volume is called the root directory.

The root directory uses the same name as your disk.

Subdirectories are ProDOS' way of organizing information on a disk.

Think of the root directory as a file drawer and the subdirectories as folders within the drawer. You can

- 1) Put files directly into the root directory like putting documents straight into the file drawer