

| | |
|---|----|
| Finding the RamFactor Card | 37 |
| Finding RamFactor's Size | 37 |
| Finding Size via ProDOS Status Call | 38 |
| Finding Size via Screen Holes | 39 |
| Finding Size via RamFactor Memory | 39 |
| Protocol Converter | 40 |
| Description of the Protocol Converter | 40 |
| Using the Protocol Converter | 41 |
| Description of Protocol Converter Commands | 43 |
| E: A Brief ProDOS Tutorial | 47 |
| Operating System | 47 |
| Naming Volumes | 47 |
| Root Directory and Subdirectory | 47 |
| Pathname | 48 |
| System Files | 48 |
| Additional Resources | 49 |
| F: Getting Help | 50 |
| Returning a Product | 51 |
| RMA Number , "Attention" Sheet, and Invoice | 51 |
| When You Ship | 52 |
| When We Receive | 52 |