

TRENDCOM 100 AII INTERFACE

OPERATING INSTRUCTIONS

The Trendcom 100 AII Interface is designed to plug directly into an Apple II Computer. Installation and operation is as follows:

1. Turn off power to both the printer and the computer.
2. Remove the cover from the Apple.
3. Plug the AII Interface board into any available slot except slot zero (0).
4. Dress the cable over the back of the Apple and replace the cover.
5. Plug the cable into the rear connector on the Trendcom 100. The cable must lay to the left of the connector, when viewing the printer from the rear.
6. Turn on both the Apple and the Trendcom 100.
7. In BASIC mode, activate the printer by typing PR#n (return), where n is the slot number used for the interface.
8. Test by typing PRINT 5+6 (return). The printer should print:
PRINT 5+6
11

LIMITED WARRANTY

Trendcom warrants this product to be free from defects in material and workmanship at the time of manufacture. Trendcom will, at no charge, repair or replace any defective unit returned within 90 days from the date of purchase; provided such defect was not caused by abuse, misuse, or modification.

Trendcom expressly disclaims any liability for consequential damages of any kind arising from or connected with the use of its products.

This warranty is in lieu of all other warranties expressed or implied and no representative or other person is authorized to represent or assume for Trendcom any warranty liability beyond that set forth herein.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

