

# Seven Hills

## SOFTWARE

Seven Hills Software Corp.  
2310 Oxford Road  
Tallahassee, FL 32304-3930

### Technical Questions

(904) 576-9415, M-F, 11am-5pm ET  
America Online, AppleLink, GENie: SevenHills  
CompuServe: 75300,1743

### Orders and General Information

(904) 575-0566, M-F, 9am-5pm ET  
FAX (904) 575-2015

Apple IIgs is a registered trademark of Apple Computer Inc.  
3M Head Cleaning Diskette Kit is a trademark of 3M Corporation  
Drive Cleaner is a trademark of Seven Hills Software Corporation  
Drive Cleaner © 1992 Seven Hills Software Corporation  
All Rights Reserved

# Drive Cleaner™ GS

Drive Cleaner combines exclusive software with the 3M head cleaning diskette and fluid to provide safe, efficient cleanings for sensitive drive heads. Replacement cleaning diskettes and fluid are available from authorized 3M Data Storage distributors. This package contains:

- 1- Drive Cleaner program disk
- 1- 3.5" head cleaning diskette (provides 30 cleanings when used with Drive Cleaner)
- 1- Bottle of head cleaning solution
- 1- Drive Cleaner booklet (you're reading it now)

***Carefully read these instructions  
before using Drive Cleaner!***

## The Cleaning Diskette

The enclosed 3M head cleaning diskette can be used on single- and dual-headed drives. However, once it is used for dual-headed drives it *cannot* be used on single-headed drives or it *will* cause damage to the drive.

All Apple IIgs 800K or High Density disk drives are dual-headed, so remove the tab from the front of the cleaning diskette. Remember: Once the tab is removed the diskette *cannot* be used on a single-headed drive or it *will* damage the drive.

## Using Drive Cleaner

Follow these steps to start the Drive Cleaner program:

- ① Start your computer as you normally do (using either a hard drive or a 3.5" system disk).
- ② When you can launch an application, insert the Drive Cleaner program disk into the 3.5" disk drive. *If you do not have a hard disk drive skip to step ⑤.*
- ③ Copy the Drive Cleaner program onto your hard disk drive (if you are using the Finder, drag the Drive Cleaner program icon onto the hard drive icon).
- ④ When the copy process is complete, eject the Drive Cleaner disk (if you are using the Finder, drag the Drive Cleaner icon into the Trash to eject the disk and remove its icon from the desktop).
- ⑤ Launch the Drive Cleaner program (if you are using the Finder, click on the Drive Cleaner program icon to select it, then choose "Open" from the File menu).

Using Drive Cleaner is easy...operating instructions are conveniently located on the screen. The first time the program is started you will be asked to enter your name. After typing your name then clicking OK, the main Drive Cleaner window will appear and all 3.5" disks will be ejected.

Follow the steps on the screen to clean the heads of one or more of your 3.5" disk drives (the drive heads are cleaned at step 2). *NOTE: Because the cleaning diskette has a different texture, it will be noisier than a regular disk.*

Drive Cleaner can be used to clean 5.25" disk drives (you must purchase a 5.25" cleaning diskette separately). To clean a 5.25" disk drive, choose "Clean a 5.25" Drive" from the Special menu. Select the 5.25" drive to clean, apply the cleaning fluid to the cleaning diskette, insert the cleaning diskette into the drive, then click the Clean button.

**CAUTION:** *The head cleaning fluid is flammable and irritating to the eyes. When not in use, keep the bottle tightly closed and away from heat, flames, and children.*

Drive Cleaner remembers how many cleanings have been performed for each kind of disk drive and provides advance warning when it is time to purchase a new cleaning diskette.

**IMPORTANT:** *Do not use the cleaning diskette if it becomes visibly dirty or worn—discard it and use a new one! If you must replace a cleaning diskette prematurely, choose the "Reset Cleaning Counters" option from the File menu to reset the appropriate cleaning counter.*

It is recommended that head cleaning be performed weekly, or every 40 hours of operation. Follow these steps to be reminded when it's time to clean your disk drive:

- ① If you have already quit Drive Cleaner, start it again.
- ② When the main Drive Cleaner screen is visible, choose "Preferences" from the Edit menu.
- ③ In the Preferences dialog box, click the checkbox next to "Remind me to clean my drives every 7 days."
- ④ Click OK to save the preferences.

When the reminder comes due seven days from today, a notice will be shown shortly after starting the computer.

*The "Read Me" file (located on the original Drive Cleaner program disk) contains additional information about the software and why head cleaning is important.*

## Drive Cleaner Limited Warranty

Seven Hills Software Corp. warrants that the Drive Cleaner program disk is free from defects in material and manufacture under normal use for a period of ninety (90) days from the date of purchase. If the program disk is found to be defective during the warranty period, Seven Hills Software's only obligation, and your exclusive remedy shall be, at Seven Hills Software's option, either (a) replacement of the Drive Cleaner program disk, or (b) refund of the purchase price of the product; provided the head cleaning diskette or program disk has not been damaged through misuse, abuse, accident, neglect or mishandling. For warranty service send the defective product and proof of purchase to:

### Customer Service

Seven Hills Software  
2310 Oxford Road  
Tallahassee, FL 32304-3930

SEVEN HILLS SOFTWARE SHALL NOT BE LIABLE FOR ANY DIRECT, CONSEQUENTIAL, OR INCIDENTAL LOSS OR DAMAGE. THE DURATION OF ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THIS WARRANTY. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

## Cleaning Diskette Limited Warranty

*3M Corporation does not warrant the Drive Cleaner program disk or software.*

3M Corp. warrants that this 3.5 inch head cleaning diskette kit is free from defects in material and manufacture under normal use for a period of one (1) year from the date of purchase. If this product is found to be defective during the warranty period, 3M's only obligation, and your exclusive remedy shall be, at 3M's option, either (a) replacement of the head cleaning kit, or (b) refund of the purchase price of the product; provided the head cleaning kit has not been damaged through misuse, abuse, accident, neglect or mishandling. For warranty service send the defective product and proof of purchase to:

### Customer Service

3M Data Storage Products Division  
3M Center Bldg. 223-55-01  
St. Paul, MN 55144-1000

3M SHALL NOT BE LIABLE FOR ANY DIRECT, CONSEQUENTIAL, OR INCIDENTAL LOSS OR DAMAGE. THE DURATION OF ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE IS LIMITED TO THE DURATION OF THIS WARRANTY. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.