



**ROBO
SYSTEMS**

ROBO SYSTEMS INTERNATIONAL, INC. / 105 Terry Drive / Newtown, PA 18940 / (215) 579-1344
FAX (215) 860-6993

ROBOCAD 2

VERSION 2.7

1) APPLE MOUSE

CAD-2 Version 2.7 now lets you select between the Apple Mouse and the Robo Controller as input devices. The selection is made in the configuration menu before the program is run. If you wish to use the Apple Mouse, specify slot 4 next to the Mouse Interface prompt. Otherwise, leave the entry next to Mouse Interface set to NONE. The program will then use the joystick controller automatically.

Instructions for using the controller are as outlined in the CAD-2 User's Manual with the following exception:

*It is necessary to watch the screen prompts during text entry -
Version 2.7 uses the <ESCAPE> key to exit many of these functions
(instead of the <LEFT> and <RIGHT> controller buttons).*

The following rules can be applied when using the Apple Mouse:

- 1) Where the manual instructs to press the **LEFT** button, press the **Open Apple** key on the Apple IIe and Apple IIgs keyboards.
- 2) Where the manual instructs to press the **RIGHT** button, press the **Closed Apple** on the Apple IIe and the **Option** key on the Apple IIgs.
- 3) Where the manual instructs to press the **RED** button, press the **Mouse** button.
- 4) Where the manual instructs to turn the **TW** (theta/scale wheel), use the **UP** or **Down Arrows** to scale.

The following are specific to using the Apple Mouse:

1) It is not necessary to hold down the **RIGHT** button to make menu and palette choices. Simply move the cursor onto the option and press the **Mouse** button to make a selection.

2) Hold down the **RED** (or **Mouse**) button when changing the angle lock or grid spacing.

3) Press the **Mouse** button to make choices from the **UTILS** menu.

2. DIMENSION TERMINATORS

CAD-2 now lets you select between three different dimension terminators. When you select **DIMN** for the first time, the arrow-type is requested. The options are:

- A) Open Arrowhead
- B) Slash
- C) Solid Arrowhead

You are required to type in a capital A, B, or C.

3. DISK PROTECTION

CAD-2 diskettes are no longer copy protected. Make as many backups as you like, backups will save you from 'down-time' if the master disk fails. Reserve the masters for generating working copies only, use the backups for day-to-day use.

4. LIBRARY DRIVE NUMBER

CAD-2 allows you to specify how many drives you want to use. Under the Configure System option of the System Menu is the option **Library Drive Number**. If you have an Apple with a single 5 1/4" disk drive, enter 1. If you have two drives and wish to use both, enter 2.