

## SPECIAL NOTICE TO FRANKLIN COMPUTER OWNERS

The Franklin computer has a different internal layout than the Apple. The card installation is pretty much the same except that the slot corresponding to the fourth one from the end in the Apple is actually fifth from the end. However, the marked number next to the fifth slot from the end in the Franklin is correctly marked as 4.

The two pin plug on the Sound Master must be attached to the plug underneath the keyboard. The best way to find this plug is to first locate the speaker on the upper left side of the keyboard and follow the wire to its source. You will have to remove the screws at the bottom of the computer and lift the keyboard in order to attach the plug.