

RamFAST/SCSI

25 NOV. 1992
30

Installation

25 NOV. 1992

and

25 NOV. 1992

Owner's Manual

25 NOV. 1992

(C) Copyright 1992, C.V. Technologies

No

All rights reserved

3

Ex 1/2

CV_T C.V. Technologies

July 27, 1992

Table of Contents

Limited Lifetime Warranty	1
Introduction and Quickstart	2
Conventions used in this manual	2
Quickstart guide	3
Hardware Installation	4
System Setup	6
Format the Hard Drive	6
Making the Hard Drive Bootable	7
Installing the RamFAST/SCSI Software	8
If Problems Occur	9
RamFAST/SCSI Utilities	11
Volumes Screen	11
SCSI Utilities Screen	17
Special Features and Upgrades	20
Keys used during the boot process	20
Upgrading to 1meg of cache	21
Application Programmer's Interface	21
Trouble Shooting	22

Limited Lifetime Warranty

C.V.Technologies warrants this product against defects in materials and workmanship for as long as you, the original consumer purchaser, own it. This warranty applies only should the product fail to function properly under normal use.

During the warranty period, **C.V.Technologies** will repair (or, at its option, replace), at no charge, components that prove to be defective, provided the product is returned (shipping prepaid and properly packed) to **C.V.Technologies**.

Before returning any item you must first obtain an RMA (Return Merchandise Authorization) number. This number must be prominently marked on the outside of the shipping container and on a letter enclosed inside that lists your name, address, and the reason for returning the item. Also, your purchase receipt or other proof of original purchase and the serial number must be provided when requesting warranty service to be performed. This warranty does not apply if the serial number has been removed, defaced, or altered, or if, in the opinion of **C.V.Technologies**, the product has been damaged by accident, misuse, neglect, improper packing or improper modifications.

This warranty is in lieu of all other express warranties, statements, or representations, and unless stated herein, all such warranties, statements, or representations, made by any other person or firm are void.

In the event that this product shall prove defective in workmanship or materials, your sole remedy shall be the repair or remedy as stated in this warranty, and under no circumstances shall **C.V.Technologies** be liable for any loss or damage, direct, incidental, or consequential, arising out of the use of, or inability to use, this product caused by any defect in the product.

C.V.Technologies
1800 East Whipp Road, Suite 200
Kettering, OH 45440

(C) Copyright 1992, C.V.Technologies, All rights reserved. Brand and product names are registered trademarks of their respective holders.

Introduction and Quickstart

If you are upgrading the ROM(s) on your RamFAST/SCSI from a version previous to V3.0 you should have gotten an instruction sheet with the ROM(s) with instructions on how to install a ROM chip. Just follow the installation instructions on that sheet and you should be all set. You should still browse through the manual to get yourself familiar with the differences between V3.0 and the version that was installed previously. One thing to be aware of if you are upgrading from a previous version of the RamFAST/SCSI is that the tape backups made by versions previous to V3.00 are not compatible with the current software in the RamFAST/SCSI.

Conventions used in this manual

Sn (where n can be 1, 2, 3, 4, 5, 6, or 7) is used to refer to a slot number in your computer.

Dn (where n can be 1 or 2) is used to refer to which ProDOS 8 drive number is assigned to a volume (or partition if you prefer). Together then, S7,D2 refers to Slot7, Drive2. If you are still lost then you should read the chapters in your computer's user's manual that refer to ProDOS 8 and disk drives.

It is assumed that you will be using a mouse to interact with the utility program. If this is not the case (i.e. He users and mouse haters) the following steps can be used to reproduce the actions of the mouse:

- 1 To execute commands that the mouse clicks on at the top of the screen you can hold down the <OPEN-APPLE> and the highlighted letter in the command at the same time. For example, to execute the ScsiUtils command (the letter "U" is highlighted) you would hold down <OPEN-APPLE> and <U> at the same time.
- 2 When told to select something you can move the cursor bar with the arrow keys and select the item you want by pressing <RETURN> or <SPACEBAR> when it's highlighted.

Quickstart guide

- 1 If you already have data on the drive **BACK IT UP!**
- 2 Open the case, plug in the RamFAST/SCSI into any available slot (except slot3), and connect the hard drive. (Most people install a hard drive controller in S7.)
- 3 Make sure that the control panel setting for the slot holding the RamFAST/SCSI is set to "Your Card".
- *4 If necessary, format and partition the hard drive using the RamFAST/SCSI Utilities program. It's especially important to do this if your hard drive is formatted at an interleave other than 1:1.
- *5 Install the operating system from floppy or restore your backup to the hard drive.
- 6 Boot the hard drive, run the RamFAST.System program (it's on the ROMDISK volume (CVTech.ROM)), and execute the **Install** command to copy the RamFAST/SCSI System Files onto the hard drive.
- 7 Now disable the ROMDISK with the **Options** command. (The ROMDISK overrides your second partition as long as it is enabled!)
- 8 That's all folks.
- * These steps are not necessary if you are just upgrading from a previous version of the RamFAST/SCSI.

If this list makes no sense whatsoever then you should just go on to the chapters on Hardware Installation and System Setup and follow the step-by-step instructions for getting the RamFAST/SCSI up and running.

Hardware Installation

This chapter covers the steps necessary to physically install the RamFAST/SCSI into your computer. The only tool you should need is the hex wrench that should have come with your computer so that you can tighten the cable on the RamFAST/SCSI to the back of your computer. Also, if the hard drive has already been used with another controller **MAKE SURE YOU HAVE BACKED UP ANY DATA ON THE DRIVE BEFORE YOU CONTINUE.**

NOTE: If you are installing the RamFAST/SCSI with a Sider hard drive you need to check the back and bottom of the Sider hard drive for a plate or sticker that says something like this: "This drive supplies terminator power to the bus. Make sure you modify the controller board to NOT supply terminator power." If you find such a warning you **MUST** remove the jumper that is in the upper left hand corner of the RamFAST/SCSI (just above where the cable connects, it's labeled JP1). If you are **NOT** installing the RamFAST/SCSI with a Sider hard drive you can ignore this paragraph.

Here now is a step-by-step list of things to do to install the RamFAST/SCSI controller card in your computer:

- 1 If more than one drive is being installed make sure that they all have unique SCSI ID's. A SCSI ID number is an "address" on the SCSI bus for the device; it has no connection with the slot number that you install the RamFAST/SCSI in.
- 2 Turn off the power to your computer and all of your peripherals.
- 3 Remove the cover of the computer.
- 4 If there is another controller card for the drive installed, detach it's cable from the back of the computer and remove the old card from the computer.
- 5 Install the RamFAST/SCSI in an available slot in the computer. Most people install a hard drive controller in slot7; however, it is possible to install the RamFAST/SCSI in any open slot (except slot3). If you are installing the RamFAST/SCSI in a IIGs you need to make sure that the setting in the control panel for the slot you selected is set to "Your Card". If you don't know what the control panel is then you need to read the chapters in your computer's user's manual that refer to the Control Panel.

- 6 Now the end of the cable should be attached to the back of the computer. You just remove the hex shaped screws from the cable, insert it into an available hole in the back of the computer, and then screw the screws back in from the outside of the case to hold it in position. Check to make sure that the connection to the RamFAST/SCSI has the cable installed so that the red wire (it might be blue) is toward the bottom of the board. Ribbon cables have one wire painted a different color to designate pin 1. Do NOT go by the orientation of anything that may be written on the cable itself!
- 7 Replace the cover of the computer.
- 8 It's now time to prepare the hard drive for use. Turn to the next chapter (**System Setup**) for instructions on how to install an operating system (ProDOS 8, GS/OS, etc.) onto the hard drive.

System Setup

If you bought your RamFAST/SCSI and hard drive as a package they should be configured to work together from the start. If that is the case your hard drive should boot right up after the hardware installation is done and you can skip the rest of this discussion and start using your hard drive. Otherwise, continue reading for information on how to get your system up and running.

If this is the first time you have used your computer with the RamFAST/SCSI the utility program should auto-boot on its own, but if for some reason it does not you can force it to by holding down the "0" key when you turn on your computer (make sure that you hold it down until a few seconds AFTER the the RamFAST/SCSI displays its "Searching the SCSI bus . . ." message or until the utility program appears.

Once you are in the utility program go ahead and click << OK >> if an any messages appear ("Configuration Data Missing" is the most likely).

Format the Hard Drive

If the hard drive has any data on it that you want to save you should skip this step (at least for now) until you have backed up the hard drive.

Click on the command **ScsiUtils** at the top of the screen. If you only have one drive attached the screen should change to the SCSI Utilities screen. If you have more than one drive attached you should first be presented with a list of Online SCSI Devices; you should select the drive that you want to work with from the list.

If, when you click on **ScsiUtils**, you are presented with a message stating that "The RamFAST/SCSI did not find any SCSI devices . . ." then you should turn everything off again and check to make sure that the card and cables are installed correctly. If you still get the message you should turn to the **Trouble Shooting** section and read about possible causes/solutions for this message.

If, once you make it to the SCSI Utilities screen, you see your par-

titions listed under the column labeled **Partition Name** and the entry for **Interleave** at the top of the screen is **1:1** it is not necessary to re-format the hard drive. If you see your partitions, but the **Interleave** is something other than **1:1** it is strongly recommended that you go ahead and re-format the drive; running with an **Interleave** other than **1:1** will slow the RamFAST/SCSI down a lot. If you don't see any partitions listed under **Partition Name** you will have to format the hard drive in order to use it with the RamFAST/SCSI.

To format the drive just click on **Format**. If the drive you are formatting is a SASI drive (Siders) you will then be asked to specify which one it is. After that you will be presented with a message telling you that **Format** will wipe out any data on the drive! If you have data on the drive that is not backed up STOP NOW and BACK IT UP! We are not responsible if you click << OK >> but didn't mean it.

Formatting the drive can take anywhere from a few seconds to several minutes (and up to 30 minutes for a Sider D2). After the formatting is completed the RamFAST/SCSI will put a default set of partition(s) on the drive (it makes as many equal sized partitions as it can). If you want to change the size and/or names of the partitions you should read the section **RamFAST/SCSI Utilities**.

Once you are satisfied with the partitions you can click on **Quit**. Once you are back at the **Volumes** screen you should see your partitions listed under GS/OS Volumes. It's now time to move on to the next section and install the system software onto the drive.

Making the Hard Drive Bootable

If you are still looking at the **SCSI Utilities** screen go up and click on **Quit**. You should now be at the **Volumes** screen. Go up and click on **Quit** again. You should get a message with two choices: << SELECT >> and << BOOT >>.

If you received the hard drive pre-formatted from the seller you should be able to select << BOOT >>. If it boots up, great! If you get the message "UNABLE TO LOAD PRODOS" or the system just hangs then you need to shut off the computer and turn it back on while holding down the <0> key. This should take you back

to the **Volumes** screen. Now just click on **Quit** again and this time pick << SELECT >>.

If you just formatted the hard drive or you landed here because << BOOT >> didn't work then click on << SELECT >>. On the left hand side of the screen a cursor bar will appear. You need to make sure you have a current system disk in your 3.5" or 5.25" drive and know what slot is associated with that floppy drive. Move the cursor bar so that the slot for the 3.5" or 5.25" drive with the disk in it is highlighted and press <RETURN>. You should now be booting the floppy.

If you are using a IIgs you should now read up on the Installer if you are not familiar with it and use it to Install the current GS/OS operating system on your first hard drive partition.

If you are using an Enhanced Iie you should use Copy II Plus (or any file copying program that you are familiar with) to put a copy of ProDOS8 and whatever else you want on the hard drive. Keep in mind that ProDOS8 loads the first .System file that it finds so the first one you copy onto the hard drive should be some type of program launcher like Prosel, Squirt, or any of the others that are floating around out there.

It's now time for the acid test... turn off the computer, turn it back on, and it should boot your hard drive. If it doesn't, try going through the installation again making sure to follow each step in order. If the hard drive boots like it's supposed to your almost done. The only thing left to do is go on to the next section and install the RamFAST/SCSI System Software.

Installing the RamFAST/SCSI Software

You should now be sitting at the GS/OS Finder screen or whatever you use as a program launcher.

If you are using the GS/OS Finder you need to open (double-click) the drive icon labeled **CVTech.ROM**. Inside you will find two files: RamFAST.System and RamFAST.Driver. Double-click on RamFAST.System (this is the Utility Program). You should see the **Volumes** screen.

First, go up and click on **Install**. You will be asked to select the volume to install the system files on. Click on the the first partition listed under GS/OS Volumes. You should see a message at the top of the screen informing you that we are copying the files onto the hard drive (NOTE: if you are installing onto a IIe then only one file is copied).

Now go up and click on the **Options** command. Click on the **Yes** next to RomDISK and it should change to **No**. Also, if you DO NOT have a TranswarpGS in your computer you should click on the **Yes** next to TWGS and it should also change to **No**. Finally, go up and click on **Quit**. You should return to whatever program you used to launch the utility program (probably the GS/OS Finder).

If you are using a IIgs you should do a **Shutdown** and reboot so that the RamFAST/SCSI driver can be loaded. That's it!

If Problems Occur

If you are having problems and you have double-checked the installation, some other things you can check are:

- If you are in a IIgs, are you SURE that the setting in the Control Panel for the RamFAST/SCSI slot is set to "Your Card" and the boot slot is set to boot the RamFAST/SCSI? Double check.
- Desk Accessories - Try booting without ANY desk accessories and see if the problems go away. Many desk accessories have the potential to interfere with a DMA hard drive controller.
- TranswarpGS - If you are having problems and you have a TranswarpGS in the system then pull it out. If the problems go away you should turn to the **Trouble Shooting** section to see if your TranswarpGS is one that needs an update or if you need to disable DMA on the RamFAST/SCSI because of your memory card.
- ZipGS - If you are having problems and you have a ZipGS then pull it out. If the problems go away you should turn to the **Trouble Shooting** section to see if your ZipGS is one that needs to be upgraded.

- Lastly, can you boot a system floppy and access the hard drive? If so then you probably just haven't installed the operating system correctly.

If after this you are still having problems you should turn to the **Trouble Shooting** section for a more detailed examination of what could be causing problems in your system.

RamFAST/SCSI Utilities

The purpose of the RamFAST/SCSI Utilities program is to allow you to setup and fine tune your hard drive and RamFAST/SCSI. The program and the GS/OS driver for the RamFAST/SCSI are stored on a RomDISK that is stored in the RamFAST/SCSI. This RomDISK will show up as a volume named **CVTech.ROM** on the GS/OS Finder desktop. Under ProDOS8 it shows up as D2 of the slot that the RamFAST/SCSI is installed in. So, if the RamFAST/SCSI is installed in S7 of your computer then the RomDISK, if enabled (see **Options**), will show up as S7,D2 for use by any ProDOS8 program.

The RamFAST/SCSI stores all of it's information about your system and it's current setup on a reserved block on your hard drive(s). If this information is not found or is found to be outdated then there may be an informational message displayed as soon as the program starts up.

Volumes Screen

The program is broken up into two different sections. The first of them is what we are going to call the **Volumes** screen. The second, which we will call the **SCSI Utilities** screen, will be covered in a later section. Each screen has a command bar at the top of the screen that can be clicked on with the mouse to execute commands.

ProDOS 8 Volumes

The RamFAST/SCSI allows you to have access to all of your partitions even under ProDOS8. We do this by "mapping" entries for any or all of your volumes into the ProDOS8 device table.

You can tell us exactly where to map each volume by clicking on it's name under the column labeled **GS/OS Volumes**. You should see a cursor bar appear on the left side of the screen in the section labeled **ProDOS 8 Volumes** (it may have already been highlighted). You can now click on any slot/drive position in the ProDOS8 display and the name of the volume should move into that spot. To remove a volume from the ProDOS8 device table you can click on it's name under GS/OS Volumes and then click on the spot labeled **<UnMap Volume>**. If a volume is not currently mapped into the ProDOS8

table then the <UnMap Volume> is what will be highlighted if that volume is selected from the list of GS/OS Volumes.

Now that the latest version of ProDOS 8 (2.0.1) also has the ability to map extra volumes to free slots it's necessary to choose which method you want to use to do the mapping (since if we both do it ProDOS gets very confused). The way you map your devices into the ProDOS 8 Volumes table in the Utility Program determines who's responsible. If you map any volumes into a slot other than the slot that the RamFAST/SCSI is installed in then we will do the mapping of volumes. If you ONLY map volumes into the slot that the RamFAST/SCSI is installed in the we will let ProDOS8 handle the mapping of volumes (this is the default).

He users: You must map all of your partitions into the ProDOS8 Volumes table in order to have access to them.

ProDOS 8 Volumes (* = RamFAST Slot)		GS/OS Volumes
		System.6.0
Drive 1	Drive 2	System.Tools
S7 *System.6.0	CVTech.ROM	PROGRAMS
S6 Diskport	Diskport	DATA
S5 Smartport		
S4		
S3	RAM3	
S2		
S1		
	<UnMap Volume>	

Lookahead and Write Protect

There is a column labeled **Lookahead** next to the list of volume names. This is the largest amount of disk data that the RamFAST/SCSI will read ahead on an operating system read call in anticipation of having the data for the next call available immediately. Normally the RamFAST/SCSI will adjust this value on the fly and you shouldn't need to change it from **Auto**.

The last column in the display is labeled **WrProt**. The RamFAST/SCSI allows you to write protect any and all volumes whenever you want. This will prevent the operating system (programs) from writing to that volume. Keep in mind though that this does NOT prevent the ability to do a low level format or partition of the drive in

the RamFAST/SCSI utility program. It also does not prevent doing a built-in **Backup/Restore** to the hard drive/volume.

Backup

The RamFAST/SCSI has the built-in ability to backup and restore your hard drive to a SCSI tape drive or optionally a removable hard drive such as the SyQuest hard drives. (To allow the selection of a removable hard drive as the destination of a **Backup** command you will need to set the HD Backup Option to Yes.)

To begin the process just go up and click on **Backup**. You will be prompted for what volume(s) you want to backup. Select as many as you want. A running total of the amount of space needed for the backup is displayed in the top half of the screen. Do NOT select more than your tape can hold! (A 60Mb tape holds approx. 60000k, a 155Mb tape holds approx. 155000k, etc.)

When you have selected all of the volumes that you want backed up then go up and click on **Backup** again. You will be asked to confirm that you want to overwrite any data that may be on the tape (or the hard drive if you have enabled that option). If everything's ok then click on << OK >>.

Now, if you want you can boot up a game or anything else you want. The RamFAST/SCSI will continue to backup your hard drive in the background! Keep in mind though that your hard drive partitions WILL be WRITE-PROTECTED until the backup completes.

Restore

The **Restore** command is the partner of **Backup**. You can select any volume on a backup tape and have it restored to any volume listed under GS/OS Volumes. To begin go up and click on **Restore**. You will be prompted to select the volume on the tape you want to restore from. After you select the volume from the tape you are prompted to select the volume you want to OVERWRITE from those listed under GS/OS volumes. You will be asked to confirm that you want to overwrite any data that may be on the destination volume. If everything's ok then click on << OK >>.

It is also possible (although it's painfully slow) to restore a single file from a volume backed up to tape. Before starting this, if you are using GS/OS and the original volume is still being used under the same name as it was backed up as you will need to change it's name

to something else. This is because we are going to make the backed up volume come up on the desktop just like any other volume and GS/OS doesn't like to see two volumes with the same name online at the same time.

To begin you need to go up and click on **ScsiUtils** and select the tape drive when you are asked to choose a SCSI device. When you are on the **SCSI Utilities** screen you need to go over to the column labeled **Active** and change the entry for the volume that contains the file to "Y". Now go up and click on **Quit**. When you are back on the **Volumes** screen you should see the backed up volume listed as one of those under **GS/OS Volumes**. Now you can click on **Quit** again and access the backed up volume just like a (VERY SLOW) hard drive.

Options

If you go up and click on **Options** you will see the following menu appear (the Yes's and No's will vary according to your setup).

Options	DMA	Yes
Menu	TranswarpGS	Yes
	AutoSave	Yes
	Mouse	Yes
	Password	No
	RomDISK	No
	HD Backup	No
	Short Timeout	No

Each of these settings affects the way that the RamFAST/SCSI works in your system. To change an Option just click on the current setting next to the Option you want to change. The following is a short description of each option:

- **DMA** - This setting is used to determine whether the RamFAST/SCSI should use DMA in your system. If you have a non DMA-compatible memory card installed in your system you should set this to No.
- **TranswarpGS** - Pretty self-explanatory. If you have a TranswarpGS installed in the system then make sure this option is set to Yes. If it's not you will not be able to work.

- **AutoSave** - If this option is Yes (the default) then every time you quit out of the program the current configuration will be saved to disk. This is used to keep everything up to date. If you flip this option to No you will have to explicitly click on the **Save** command to update the saved configuration data.
- **Mouse** - If you are in a IIGS and don't want to use the mouse for some reason you can set this option to No.
- **Password** - If you don't want people to be able to change your RamFAST/SCSI configuration without your knowing it you can set a password for access to the utility program. Make sure you are VERY careful when you set a password as they are CASE SENSITIVE.
- **RomDISK** - This setting should normally be No after you get your system setup and running. You can always bring up the utility program if you need to by holding down the <0> key when you turn on your computer.
- **HD Backup** - Normally the built-in **Backup** and **Restore** only deal with tape drives. If you wish to be able to backup to a (presumably removable) hard drive you need to set this option to Yes. Now you will be asked to choose the destination/source device whenever you click on **Backup** or **Restore**.
- **Short Timeout** - If you normally leave some of your SCSI drives powered down (such as a tape drive or CD) you can set this option to Yes to get rid of the 45 second delay at power-up while the RamFAST/SCSI is waiting on those devices to appear. Be aware that if you do set this option to Yes you will need to power-up your hard drive before you turn on your computer.

Also, if you have one of the newer RevD RamFAST/SCSI cards and you set the TranswarpGS option to No then the setting for DMA is ignored. This is because the RevD RamFAST/SCSI card can DMA into any memory card, independent of its DMA compatibility, provided you DO NOT have a TranswarpGS in the system.

Install

The **Install** command is usually only used when you are first setting up the RamFAST/SCSI. It is used to place copies of RamFAST.System and RamFAST.Driver onto the hard drive. To install these files just go up and click on **Install** and you will be prompted

for which volume to install the files on. Just click on the name under GS/OS Volumes.

Save

The **Save** command is used to save the current RamFAST/SCSI configuration data to the hard drive. You shouldn't have to use this command unless you set the AutoSave option to No.

ScsiUtils

The **ScsiUtils** screen allows you to **Format** and **Partition** your hard drive. It also allows you to control whether a partition is visible to the operating system (Active) or ignored (Inactive). For those of you with very old hard drives there is also a **Headpark** command. And lastly there is a **Rewind** command for use with tape drives.

When you first go up and click on **ScsiUtils** in the **Volumes** screen, if you have more than one (1) SCSI device attached to the RamFAST/SCSI you will be prompted to select which one you want to work with from a list like the one below.

Online SCSI Devices

```
ID7
ID6 SyQuest SQ555
ID5
ID4
ID3
ID2 Sony CD-ROM CDR36
ID1
ID0
```

Once you have selected a device (if you only have one (1) it is selected for you automatically) the screen should change and you should see a display of information about the device on the top half of the screen and a list of all of the partitions on the drive on the bottom of the screen. This is the **SCSI Utilities** screen.

SCSI Utilities Screen

At the top of the screen is a display similar to the one below. The major entry to take note of (for hard drives) is the value for **Interleave**. If the interleave is not 1:1 you should definitely consider reformatting the hard drive. Any interleave other than 1:1 will slow the RamFAST/SCSI's performance down considerably (2:1 cuts it in half, 3:1 cuts it to a third, etc.). (Some Sider hard drives are an exception to this. If you have a Sider SASI hard drive the best interleave that they support is 4:1.)

Device Name	SYQUEST SQ555	SCSI ID	6
Serial Number		Interleave	1:1
		Cylinders	1067
Device Size	43328k	Sectors/Track	64
Space Available	320k	Heads	2
		Defect List Size	48

Format

The **Format** command performs a low-level format of the hard drive or tape. This **WILL** erase any data that may be on the drive so make sure you have a backup if you need anything that's on it!

After the format completes a default set of partitions will be created on the hard drive. If these are satisfactory you can just **Quit** now and continue on with whatever is next. Otherwise read on and find out how you can change the size and/or name of the partitions.

Add/Delete

The **Add** and **Delete** commands are kind of a linked pair. They are used to add a new partition to the list at the bottom of the screen or to delete the currently selected partition. You can add up to a total of twelve (12) partitions onto any single drive. If you wish to change the name just select the partition that you wish to change and press the <DELETE> key. The line will clear and you will be able to type in a new name; after you finish with the name just press <RETURN>.

Resizing Partitions

To change the size of a selected partition you can use the mouse to click on one end or the other of either thermometer to decrease or increase it's size by the amount stated under that thermometer. The left side of the thermometers decrease the size and the right side increases the size.

If you are not using the mouse you can adjust the size in 1Mb increments by holding down the <OPEN-APPLE> key and the left or right arrow keys. You can adjust the size in 32k increments by holding down the <OPTION> (or <CLOSED-APPLE> on a Iie) and the left or right arrow keys.

```

                                Partition Name
                                System.6.0
<<:::::::::::::::::::::::::: >>  System.Tools
0 Adjust Size by +/- 1mb      32+mb  PROGRAMS
                                DATA
<<                             >>
0 Adjust Size by +/- 32k     1024k

```

Partition

The **Partition** command is used to write a new partition map to the drive that corresponds to the list of partitions in the bottom half of the screen. Any partitions less than or equal to 32Mb in size will also have a blank ProDOS directory structure put on them. Partitions larger than 32Mb will not be formatted by us (no space in the ROM for the necessary code to format HFS style). GS/OS will say that it does not recognize it so you should go ahead and format it using the HFS file system (ProDOS can't use partitions larger than 32Mb).

Headpark

The **Headpark** command is not necessary on any drive manufactured in the last few years. All drives manufactured today have an auto-headpark feature. If you do need to park your heads you can use this command or create a .system file using the code fragment below to do it for you. (If the code fragment below is meaningless to you just ignore it.)

```

jar      $c70d      * Assumes card is in Slot7
db       $08

```

```

dw      ?parameters
rts                                           * Ignores errors
?parameters
db      $05
db      $86                                 * Assumes Scsi ID 6
dw      ?headpark
db      $FF
dw      $0000
dw      $0000
?headpark
db      $1B,$00,$00,$00,$00,$00,$00,$00,$00,$00,$00,$00,$00
b1kb   $40,$00

```

Rewind

Rewind can be used to rewind a tape in a tape drive that is not at the beginning. This shouldn't really be needed since the built-in **Backup** and **Restore** commands rewind the tape before doing any processing.

Active vs. Inactive Partitions

The last column in the display at the bottom of the screen is labeled **Active** and has entries below it that say "Y" or "N". What this means is that you can selectively choose which partitions you want the system to have access to at any given time. The main use for this feature is for those of you with multiple hard drives with a total of more than twelve (12) partitions. This allows you to switch among the partitions you want to have access to up to a maximum of twelve at a time.

Special Features and Upgrades

Keys used during the boot process

One thing that has only been mentioned in passing up to now is that the RamFAST/SCSI also allows you to change the way it behaves at power up by holding down certain keys. It is also possible to use these keys when you do an Open-Apple/Control/Reset, but this might seem better suited to an octopus.

If you hold down a number key from “1” through “9” when you turn the power on then the partition in the Logical Devices list corresponding to the number held down is booted. For example: holding down the “2” key will boot the second partition in the list; holding down the “6” key will boot the sixth partition in the list; etc. This can be very handy if you sometimes want to boot GS/OS and other times want to boot ProSel or even ProDOS8. One thing to be aware of is that the selected partition becomes the default boot partition until another key is held down or you turn off the power to the computer. You can make the change permanent by running The Utility Program and saving the current configuration.

Also, if you hold down the “0” key at power up the utility program will boot. This can be handy if you have lost or misplaced the copy of the utility program that the **Install** command put on your hard drive.

Lastly, if you hold down the space bar the RamFAST/SCSI will “basically cease to exist.” It will not put partitions in its device list and will just immediately boot through to the next slot. This is handy if you (or maybe your kids) want to boot something on 3.5” or 5.25” disks without having to worry about your hard drive. If you want to do this with the hard drive powered down or disconnected you will have to have the jumper (JP1, just above where the cable plugs onto the card) installed or the RamFAST/SCSI will crash immediately into the monitor. To get the partitions back after you have booted this way you can turn the power off and back on or perform an Open-Apple/Control/Reset while holding down a number key. This will tell the RamFAST/SCSI to rebuild its partition table and boot the selected partition.

Upgrading to 1meg of cache

The RevD RamFAST/SCSI is upgradable from 256k of cache to 1meg of cache. To do the upgrade yourself you will need to order "two (2) 1meg x 4 DRAMs in a 300mil DIP package." The Toshiba part number for these chips is "TC514400AP-10 or -8"; they should be able to convert from this part number to whatever manufacturer's chips they have in stock.

After you receive the new memory chips all you need to do is pry the old memory chips (U19 and U20 in the upper right hand corner of the board) out of their sockets with a small flathead screwdriver. Now put the new chips in the sockets making sure that the notch on the one end of the chip points to the TOP of the board (same as the old chips) and that none of the pins are bent under or out of the socket.

Application Programmer's Interface

The V3.xx RamFAST/SCSI includes a number of documented calls that are made using the Smartport entry. An example of one of these calls is given in the chapter concerning the **SCSI Utilities** screen in the section **Headpark**. Send a check or money order for \$20.00 to: C.V.Technologies, 1800 East Whipp Road, Kettering, OH 45440 requesting the RamFAST/SCSI API Documentation if you want more information on the supported calls and their parameters.

Trouble Shooting

The first thing to do if you are experiencing problems is to make sure that all of the cables are plugged in securely, that the power is turned on to all of your drives and your computer. If everything seems to be installed correctly, scan through the list of problems below, read the descriptions, and follow the directions for any of them that apply to your system.

All computers

Terminating Resistor Plugs

There should only be one (1) set of terminating resistors installed on the SCSI bus. This usually takes the form of an external terminator plug that is installed in the daisy-chain connector of the last drive in the chain. Some drives are supplied with internal terminators. If you know this to be the case with your drive you do not need an external terminator. If you are not sure whether your drive has internal terminators installed you can consult the documentation supplied with it or contact the seller of the drive and ask.

Terminator Power

Continuing the discussion of terminating resistors, at least one device on the SCSI bus must supply power for these terminators. If your drive(s) do not supply terminator power to the SCSI bus you need to make sure that the jumper in the upper-left corner of the RamFAST/SCSI (JP1) is installed. If you are not sure whether your drive supplies terminator power you should consult the documentation supplied with it or contact the seller of the drive and ask. If your drive (most notably Siders) has a sticker on the back of it saying that the drive supplies terminator power and the controller card should be modified NOT to then you MUST remove the jumper. Note that this is the only case where it should be necessary to remove that jumper; it is usually perfectly fine for the card and the drive to both supply terminator power (with the exception of the Sider drives previously mentioned).

Cables

If you have checked all of your cables and they seem to be tightened down correctly it's time to think about the length of the cables. Long cables (6' or more) can cause problems at the speed that the RamFAST/SCSI operates, especially when connecting multiple drives the the RamFAST/SCSI. If you are having problems and you have a long cable it is worth a try if you can to try a shorter one.

Your Power Supply

If you have a number of cards installed in your computer and you still have the "stock" power supply that came with your computer you may experience problems with the RamFAST/SCSI ranging from random crashes to total failure to function. This is especially a problem in an Apple IIgs with an \mathcal{A} E TranswarpGS, an \mathcal{A} E PC-Transporter, and a RamFAST/SCSI. This can also be a problem in an Apple IIe if there are a lot of peripherals installed. If it sounds like this could be the case you should remove some of the cards installed in your computer and see if that cures your problems. If it does, you should definitely consider getting a heavy duty power supply before reinstalling everything in your computer.

CMS Hard Drives

There is a set of DIP Switches on the back of most CMS hard drives. One of these switches controls how the drive is "talked to". You must turn on the DIP Switch that makes the drive compatible with the Apple Macintosh. If you are not sure how to do this you can consult the documentation supplied with the drive or contact the seller of the drive and ask.

Multiple Drives with Conflicting SCSI ID Numbers

If you have connected multiple drives to the RamFAST/SCSI you must be sure that the SCSI ID numbers assigned to the drives do not overlap. SCSI ID numbers range from 0 through 7 and no two drives on the same SCSI bus can have the same ID number. Information on how to determine and/or change the SCSI ID number of a drive should be found in the owner's manual that came with the drive.

\mathcal{A} E RamFactor

If you have a RamFactor installed in your computer and are having problems, try removing the RamFactor and see if the problems go away. Some RamFactors cause problems (especially in an Apple IIgs) just being installed in the same computer as the RamFAST/SCSI. If the RamFAST/SCSI works with your RamFactor out of the system and doesn't work if it IS in the system there's not really anything that can be done beyond removing the RamFactor.

IIe computers

Your IIe is unenhanced

The RamFAST/SCSI will NOT function in an unenhanced IIe. If you want to use the RamFAST/SCSI you will have to purchase an enhancement kit for your IIe from a mail-order firm and install it.

Apple IIe With A Number of Cards Installed

In an Apple IIe it is also possible to see the same problems described above for weak power supplies even if you have a heavy duty power supply. This is a problem that is associated with the design of Apple IIe's and there is nothing really that can be done about it. If the RamFAST/SCSI works in your Apple IIe with no (or few) cards installed and doesn't work with all of them installed then, unless one of the peripherals is mentioned below as causing specific problems, it is possible that the RamFAST/SCSI may not be able to function in this computer unless some of the cards are removed permanently.

Apple IIe Accelerators

At the time that this manual was printed, there were no DMA compatible accelerators for the Apple IIe. If you have an accelerator installed in your Apple IIe then you must not enable the DMA option in The Utility Program. If you do enable the DMA option with an accelerator installed you will encounter problems. Other things to be aware of is that the 10mHz RocketChip will not work in the same system as a RamFAST/SCSI. This is a problem with the RocketChip, not the RamFAST/SCSI and there is nothing that we can do about it. Also, some of the 8mHz ZipChips have problems in the same system as a RamFAST/SCSI. If you are having problems with an 8mHz ZipChip try replacing the ZipChip with the original 6502 processor and see if the problems go away. If they do then you need to call Zip Technologies and get it replaced.

Apple IIe 40 Column vs. 80 Column

If you are installing the RamFAST/SCSI into an Apple IIe it is required that you have an 80 Column card. The Utility Program will not function without it.

IIgs computers

Apple IIgs Control Panel Settings

In an Apple IIgs you need to make sure that the control panel setting for the slot that the RamFAST/SCSI is installed in is set to "Your Card" and that the boot slot is set to "Scan" or to the slot that the RamFAST/SCSI is installed in.

Apple SCSI Drivers

Unless you also have an Apple High Speed DMA SCSI card installed in your Apple IIgs you should disable or remove the Apple supplied SCSI drivers from the Drivers folder located in the System folder of your boot partition. The files that should be disabled or removed are: SCSI.Manager, SCSIHD.Driver, are SCASICD.Driver.

Can't run ProDOS 8 software from GS/OS

If you are having problems running ProDOS 8 software from GS/OS (prior to System 6.0) you probably have more than 8 devices in the ProDOS device table. This is a problem inherent in GS/OS. You can not have more than 8 total devices available under ProDOS if you are going to launch your applications from GS/OS (Note: this is not a problem if the hard drive boots ProDOS 8 directly). To see if this may be the problem, total up all of your 3.5" drives, 5.25" drives, and any RamFAST/SCSI partitions you have mapped into the ProDOS Block Devices table. If the total is greater than 7 you will have this problem (the /RAM3 ramdisk gets added in too). To fix this you just need to unmap some of the partitions on the RamFAST/SCSI or possibly turn off the slot for your 3.5" or 5.25" drives if you're not using them.

Desk Accessories

If you have any of the following desk accessories or inits installed you will have problems, disable them: Mr. Apple / Fancy Apple, Twilight, Carpet Bag, FastSpeed, Ram.Namer.

Also, if you must use a screen-blanker you should use the one from Prosel or use Phantasm (from Quality Computers). If you have another one and you are having problems, try disabling it.

Zip GSx Accelerator

If you have a Zip GSx accelerator installed in your computer you need to check the version number on your board. If it is V1.01 then you need to contact Zip Technologies for a free upgrade in order to function with the RamFAST/SCSI.

IIGs with a TWGS and/or a RevC RamFAST/SCSI

Æ TranswarpGS Accelerator

If you experience problems with the RamFAST/SCSI and you have a TranswarpGS installed in your computer check to see if there is a part labeled TWGS-2A installed on your TranswarpGS. At the top right-hand side of the TWGS there are two chips with stickers on them. The top one should be TWGS-1A and the one below it should be TWGS-2B. If this chip is labeled TWGS-2A you will need to contact Æ to obtain a replacement (TWGS-2B). The RamFAST/SCSI will not function in your computer until you get this replacement part. At the time this was printed, the replacement was free of charge. If there is already a TWGS-2B part in your TranswarpGS then you should try replacing the TranswarpGS with the original 65C816 processor and see if the problems go away. If they do you may need to send

the TranswarpGS to Æ for further modification.

Æ TWGS Accelerator - RamFAST/SCSI Options

If you have an ÆTWGS in your computer you must have the Option (in The Utility Program) for TranswarpGS set to Yes. If you don't you will have problems.

Æ TWGS Control Panel - AppleTalk/IRQ

The TranswarpGS's control panel Desk Accessory has a section labeled "Configure" which in turn has the entry "AppleTalk/IRQ". You need to make sure this is ON. If it is OFF you will have problems.

Æ GS-Ram

If you have an Æ GS-Ram, revision "A", installed in your computer the RamFAST/SCSI will not function. If you have a GS-Ram with a revision "B", "C", or "D" you will have to disable the DMA option in The Utility Program in order to avoid problems. Only revision "E" of the GS-Ram is completely DMA compatible. To determine the Revision of a GS-Ram card you need to remove it from your computer and look at the supporting "leg" of the card (half-way between the card-edge connector and the back end of the card). On the front or back in this area should be a message that says "REV x" where "x" can be "A", "B", "C", "D", or "E".

Æ GS-Ram+ Rev A, CheckMate Memory, or RamPack 4GS

If you have any of these products installed in your computer you will have to disable the DMA option in The Utility Program in order to avoid problems. To determine the revision of a GS-Ram Plus use the same method described in the Æ GS-Ram problem description above.

Æ RamKeeper

If you have an Æ RamKeeper in your computer with two (2) memory cards you will have to disable the DMA option in The Utility Program. If there is only one (1) memory card installed in the BACK pocket of the RamKeeper and the memory card itself is DMA compatible you should not have any problems.

All else fails . . .

If you have read and tried everything in the Trouble Shooting section and you're still having problems then gather the following information:

- 1 What kind of computer (Ile, Iigs ROM01, or Iigs ROM03)
- 2 Serial number and software version of your RamFAST/SCSI
- 3 A list of the other cards installed in your computer
- 4 A list of the equipment attached to the RamFAST/SCSI

You can contact Tech Support by phone, fax, mail, or e-mail. The voice phone number is (513)435-5743. The fax number is (513)435-9554. E-Mail can be sent as follows:

Compuserve Send e-mail to 72260,541

GENie Send e-mail to CV.TECH

America Online Send e-mail to CVTech

Internet Send e-mail to 72260.541@compuserve.com

Warranty Registration

So that we may better serve you, please take a moment to fill out the following warranty registration, remove it from the manual, and return it to:

C.V. Technologies
1800 East Whipp Road, Suite 200
Kettering, OH 45440

Warranty Registration

What is the Serial Number of your RamFAST/SCSI? _____

Your Name _____

Your Address _____

When did you purchase it? _____

Where did you purchase it? _____

Is it being installed in a IIe or a IIgs? _____

What other cards do you have in your computer? _____

