

READ THESE STEP BY STEP INSTRUCTIONS COMPLETELY before you install your RamWorks.

- ☐ Leave your computer plugged in, but switch the //e power switch to the OFF position.
- ☐ Remove the lid from the //e.
- ☐ Make sure the power-on indicator light inside the computer is OFF. (See Illustration 2-1)
- ☐ Check the upper left corner of the computer's main printed circuit board. If the IIe copyright year is not 1982—go on to the next step. If it says Apple IIe © 1982, check the part number of the computer's circuit board located between the //e rear panel and expansion slots 3, 4, and 5. Look closely. If the number directly to the left of "©1982" is 820-0064-A please see Appendix A before installing your RamWorks.
- ☐ Discharge any static electricity that may be on your body or clothing by gently touching the power supply. ***This is important!!!*** Static electricity can ruin chips on your card and motherboard.
- ☐ Remove the RamWorks from its anti-static bag. Do not touch the gold edge connectors.
- ☐ Position the RamWorks card above the Auxiliary Slot, with the long end of the card toward the rear of the computer.
- ☐ Gently but firmly insert gold edge connector of the RamWorks into the Auxiliary Slot.
- ☐ Replace the computer's lid and the installation is complete!

You don't have to test the RamWorks, but if you'd like to, Appendix B tells you how.