

<u>F8-FF</u> Select	<u>RAM</u> Select	<u>NORMAL</u> + <u>ROM</u> Select Switch	<u>LANGUAGE</u> <u>CARD</u> + <u>COMPUTER</u> Select Switch	<u>LANGUAGE</u> <u>CARD</u> <u>RAM</u> Select	<u>ROM</u> Select
(Input)	(Input)	(Input)	(Input)	(Output)	(Output)
OFF (HIGH)	OFF(HIGH)	NORMAL (HIGH)	LANGUAGE L. CARD (HIGH)	OFF (HIGH)	(COMPUTER < F8) (L. CARD ≠ F8)
	ON (LOW)			ON (LOW)	(L. CARD <u>RAM</u>)
ON (LOW)	OFF			OFF	L. CARD
	ON			ON	(L. CARD <u>RAM</u>)
OFF (< F8)	OFF	↓	<u>COMPUTER</u> (LOW)	OFF	(COMPUTER)
	ON			ON	(L. CARD <u>RAM</u>)
ON (≥ F8)	OFF			OFF	COMPUTER
	ON			ON	(L. CARD <u>RAM</u>)
OFF	OFF	<u>ROM</u> (LOW)	LANGUAGE L. CARD (HIGH)	OFF	(COMPUTER < F8) (L. CARD ≠ F8)
	ON			ON	(L. CARD <u>RAM</u>)
ON	OFF			OFF	L. CARD
	ON			OFF	L. CARD
OFF	OFF	↓	<u>COMPUTER</u> (LOW)	OFF	(COMPUTER)
	ON			ON	(L. CARD <u>RAM</u>)
ON	OFF			OFF	COMPUTER
	ON			OFF	COMPUTER

