

GS Power™

Installation Instructions

- 1) Disconnect the power cord from the back of the computer.
 - 2) Remove the lid from the computer.
 - 3) Remove the slot one card. You'll need to give yourself room to reach the internal power plug. Refer to your slot 1 card's manual for proper removal.
 - 4) Unplug the internal cord from the motherboard. The internal power cord is the multi-wire cord running from the power supply toward the back of the motherboard. Pull up firmly on the white plastic part of the plug.
 - 5) Gently pull back on the tab at the bottom front of power supply. A small flatblade screwdriver may keep you from breaking a nail.
 - 6) Lift out the power supply. You may want to store the power supply in the GS Power's box.
 - 7) Align the three holes in the back of the GS Power with the three prongs in the back of the computer.
 - 8) Snap the GS Power down into the front tab. You should hear the tab click into place.
 - 9) Plug Internal Power Cord Into Motherboard. The connector's tab should be toward the right side of the computer.
- ❖ *Note:* Do not force the connector; it will plug in easily in one direction.
- 10) Reinstall the slot one card, close the lid, and last, reattach the power cord.

Applied Engineering

P.O. Box 5100

Carrollton, Texas 75011

Sales: (214) 241-6060 9 AM - 11 PM (CST) 7 days

Technical Support: (214) 241-6069 9 AM - 12:30 & 1:35 - 5 PM
(CST) Monday - Friday

(The Technical Support telephone lines cannot be accessed through the Sales department.)

Bulletin Board System: (214) 241-6677

8 Bit, No Parity, Full Duplex, MNP-5

Limited Warranty & Disclaimer

Applied Engineering warrants the GS Power power supply against defects in material and workmanship for a period of 1 year from the date of original retail purchase. Any misuse, abuse, or non-Æ authorized alteration, modification and/or repair to the Applied Engineering product will void the warranty. This warranty will also be void if you use the Æ product for any other purpose than its intended use. If you discover a defect, Applied Engineering will, at its option, repair or replace only the Applied Engineering product, provided you return the product during the warranty period, transportation prepaid, to Applied Engineering.

This warranty applies to the original retail purchaser only. Therefore, please include a copy of the original invoice or a small service charge may be applied. If the product is to be sent to Applied Engineering by mail, the purchaser will insure the package or assume full responsibility for loss or damage during shipping. Prior to returning the product for warranty consideration, call Applied Engineering Technical Support for a Return Material Authorization (RMA) number and shipping instructions.

Even though Applied Engineering has reviewed the documentation, Applied Engineering makes no warranty or representation, either express or implied, with respect to the manual, its quality, performance, merchantability, or fitness for a particular purpose.

In no event will Applied Engineering be liable for loss or damages of any kind caused either directly or indirectly by the use or possession of its products, even if advised of the possibility of such damages. **The Applied Engineering Warranty is for the Applied Engineering Product itself.** In particular, Applied Engineering shall have no liability for any other equipment used in conjunction with Applied Engineering products nor for programs or data stored in or used with Applied Engineering products, including the costs of recovering such equipment, programs, or data.

The warranty and remedies set forth above are exclusive and in lieu of all others, oral or written, express or implied. No Applied Engineering dealer, agent, or employee is authorized to make any modification, extension, or addition to this warranty.

This documentation is copyrighted by Applied Engineering with all rights reserved. Under the copyright laws, this documentation may not be copied, in whole or in part, without the written consent of Applied Engineering. This exception does not allow copies to be made for others, whether or not sold, but all of the materials purchased (with all archive copies) may be sold, loaned, or given to another person. Under the law, copying includes translating into another language or format.

Applied Engineering cannot guarantee that you will receive notice of revisions to the documentation or products described in this manual. Be sure to check with your dealer or Applied Engineering for information on possible updates. However, Applied Engineering reserves the right to make any improvements to Applied Engineering products without any responsibility toward upgrading previously released products.

Apple is a registered trademark of Apple Computer, Inc.
Applied Engineering is a registered trademark of Applied Engineering.

©Copyright 1990, Applied Engineering
